






Alden Satellite DSTV Decoder requirement sheet

All dishes are DUAL LNB and will be able to work on the following decoders:

If you have this	you will need this extra	<u>Additional information:</u>
<p data-bbox="286 566 452 598">Explora 1</p> 	<p data-bbox="672 566 974 598">DSTV Smart Switch</p> 	<p data-bbox="1243 566 1982 710">Dish comes with standard LNB, please refer to Decoder information to see what is necessary to purchase</p> <p data-bbox="1243 726 2038 813">When exchanging LNB's please make sure the LNB is on 120 degrees</p>
<p data-bbox="212 845 504 877">DSTV HD Decoder</p> 	<p data-bbox="705 933 929 1013">Nothing extra required</p>	<p data-bbox="1243 829 1971 917">Make sure there is no obstruction like trees and building when parked on the campsite</p>
<p data-bbox="212 1133 504 1165">DSTV HD Decoder</p> 	<p data-bbox="683 1133 952 1165">DSTV Smart LNB</p> 	<p data-bbox="1243 933 1982 1021">Make sure that it says DSTV 7&10 or IS20 on the control box</p>

All other Decoders can still be used on the Alden Dish, no special LNB is needed for these decoders

